

Notes:

- ★ **MotionPAD** requires 3 AA batteries (included).
- ★ To store the device for extended time, we suggest turning the device off and removing the batteries.

CE



Attainment Company, Inc.

P.O. Box 930160


Verona, Wisconsin 53593-0160 USA

1-800-327-4269

www.AttainmentCompany.com



The **MotionPAD** uses light sensing technology to playback a recorded message. It will play the recorded message when the sensor detects motion. The motion/light sensing range is 6½ feet (2 meters.) You record the message. The message can be up to 6 seconds and can be re-recorded anytime.



To Record:

Slide the OFF/ON switch to the ON position. Press and hold the Record button, then speak towards the microphone hole. Release the Record button to finish the recording.

The **MotionPAD** will beep-beep when the Record button is released. It will also beep-beep when the Record button continues to be held to the end of the record time.

Warranty:

Attainment Company provides a one year warranty against factory defects.